

FLUKE®

i50s
Current Probe

PSi50s
Power Supply

Users Manual

PN 2842332

June 2007

© 2007 Fluke Corporation, All rights reserved. Printed in the Netherlands.
All product names are trademarks of their respective companies.

LIMITED WARRANTY AND LIMITATION OF LIABILITY

Each Fluke product is warranted to be free from defects in material and workmanship under normal use and service. The warranty period is one year and begins on the date of shipment. Parts, product repairs, and services are warranted for 90 days. This warranty extends only to the original buyer or end-user customer of a Fluke authorized reseller, and does not apply to fuses, disposable batteries, or to any product which, in Fluke's opinion, has been misused, altered, neglected, contaminated, or damaged by accident or abnormal conditions of operation or handling. Fluke warrants that software will operate substantially in accordance with its functional specifications for 90 days and that it has been properly recorded on non-defective media. Fluke does not warrant that software will be error free or operate without interruption.

Fluke authorized resellers shall extend this warranty on new and unused products to end-user customers only but have no authority to extend a greater or different warranty on behalf of Fluke. Warranty support is available only if product is purchased through a Fluke authorized sales outlet or Buyer has paid the applicable international price. Fluke reserves the right to invoice Buyer for importation costs of repair/replacement parts when product purchased in one country is submitted for repair in another country.

Fluke's warranty obligation is limited, at Fluke's option, to refund of the purchase price, free of charge repair, or replacement of a defective product which is returned to a Fluke authorized service center within the warranty period.

To obtain warranty service, contact your nearest Fluke authorized service center to obtain return authorization information, then send the product to that service center, with a description of the difficulty, postage and insurance prepaid (FOB Destination). Fluke assumes no risk for damage in transit. Following warranty repair, the product will be returned to Buyer, transportation prepaid (FOB Destination). If Fluke determines that failure was caused by neglect, misuse, contamination, alteration, accident, or abnormal condition of operation or handling, including overvoltage failures caused by use outside the product's specified rating, or normal wear and tear of mechanical components, Fluke will provide an estimate of repair costs and obtain authorization before commencing the work. Following repair, the product will be returned to the Buyer transportation prepaid and the Buyer will be billed for the repair and return transportation charges (FOB Shipping Point).

THIS WARRANTY IS BUYER'S SOLE AND EXCLUSIVE REMEDY AND IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. FLUKE SHALL NOT BE LIABLE FOR ANY SPECIAL, INDIRECT, INCIDENTAL, OR CONSEQUENTIAL DAMAGES OR LOSSES, INCLUDING LOSS OF DATA, ARISING FROM ANY CAUSE OR THEORY.

Since some countries or states do not allow limitation of the term of an implied warranty, or exclusion or limitation of incidental or consequential damages, the limitations and exclusions of this warranty may not apply to every buyer. If any provision of this Warranty is held invalid or unenforceable by a court or other decision-maker of competent jurisdiction, such holding will not affect the validity or enforceability of any other provision.

Fluke Corporation

P.O. Box 9090

Everett, WA 98206-9090

U.S.A.

Fluke Europe B.V.

P.O. Box 1186

5602 BD Eindhoven

The Netherlands

11/99

To register your product online, visit register.fluke.com

Table of Contents

Title	Page
Introduction	1
Safety Instructions	2
Symbols	3
Probe Features	4
Probe Operating Instructions	5
Connections	5
Activating the Probe	6
Current Measurement	7
Range Selection	7
Auto Zero	8
Degauss	8
Indicators	8
Power Supply Operating Instructions	9
Fuse Rating	10
Maintenance	11
Cleaning	11
Power Supply Fuse Replacement	12
Storage	12
Specifications	13
Probe	13
Electrical Specifications	13
Dynamic Characteristics	14
General Data	14
Power Supply	15
Electrical	15
Various	16
Safety	17
Safety Standards	17
EMC Standards	17
Accessories	20
Service	20

i50s Current Probe/ PSi50s Power Supply

Introduction

⚠ ⚠ Warning

To avoid electrical shock or possible injury, do not use the i50s Current Probe with oscilloscopes with floating inputs, i.e. oscilloscopes not referenced to ground.

The i50s Current Probe (“the Probe”) has been designed for use with oscilloscopes for accurate, non-intrusive measurement of ac, dc and complex waveform currents. Using advanced Hall Effect technology the Probe can accurately measure currents over the frequency range of dc to 50 MHz with a measuring range up to 50 A peak. The Probe is a general purpose, universal current Probe which can be used with any oscilloscope.

⚠ ⚠ Warning

To avoid electrical shock or possible injury, use the PSi50s Power Supply only with i50s Current Probes.

The PSi50s Power Supply (the “Power Supply”) is an external power supply that can simultaneously power two i50s Current Probes. The Power Supply is supplied from single-phase mains 115 or 230 V ac, with frequencies from 44 to 60 Hz, and provides a symmetrical dc voltage of ± 12 V.

Safety Instructions

Please read this section carefully. It will make you familiar with the most important safety instructions for handling your product. In this manual, a **Warning** identifies conditions and actions that pose hazard(s) to the user. A **Caution** identifies conditions and actions that may damage the Probe, Power Supply, or the test instruments.










Warning

The Probe and Power Supply may only be used and handled by qualified personnel. To avoid electrical shock or personal injury, follow these precautions:

- **Use caution during installation and use of these products; high voltages and currents may be present in circuits under test.**
- **Do not use the Probe or Power Supply if damaged. Always connect the Probe to display device before it is installed around the conductor.**
- **If the Probe or Power Supply is not used in a manner specified by the manual, the protection provided may be impaired.**
- **Use the Power Supply only with i50s Current Probes.**
- **Do not use the Probe without consulting local and national safety codes and use of protection equipment is recommended.**
- **Do not hold the Probe beyond the tactile barrier (see Figure 1).**
- **Before each use, inspect the Probe and Power Supply. Look for cracks or missing portions of the housing or output cable insulation. Also look for loose or weakened components. Pay particular attention to the insulation surrounding the jaws.**
- **Use caution when working with voltages above 60 V dc, 30 V ac rms or 42 V ac peak. Such voltages pose a shock hazard.**
- **Do not use the Probe or Power Supply in wet environments or in locations that hazardous gases exist.**
- **Inspect the Power Supply and power cord and ensure that they are not damaged.**
- **This product has no serviceable parts, do not open the Power Supply.**
- **Check to make sure that the voltage selector switch on the back panel of the Power Supply is set to the correct mains input voltage before connecting power.**

Symbols

The table below lists the symbols used on the Probe and/or in this manual.

Symbol	Description
	Do not dispose of this product as unsorted municipal waste. Go to Fluke's website for recycling information.
	Important Information. See manual.
	Hazardous Voltage. Risk of electric shock.
	Do not apply to or remove from hazardous, live conductors without taking addition protective measures.
	Double insulation.
	Fuse.
	Conforms to Canadian Standards Association.
	Complies with the relevant European standards.
	Conforms to Australian standards.
CAT I	CAT I equipment is designed to protect against transients from high-voltage, low-energy sources, such as electronic circuits or a copy machine.
CAT II	CAT II equipment is designed to protect against transients from energy-consuming equipment supplied from the fixed installation, such as televisions, personal computers, portable tools, and other household appliances.

Probe Features




Figure 1. i50s Features

Probe Operating Instructions

The following sections list the Probe operating instructions.

Connections

For these connections, refer to Figures 1 and 2. To connect the Probe, do the following:

1. Connect the BNC connector, to the oscilloscope input. Ensure that the input impedance is $\geq 1\text{ M}\Omega$.
2. Connect a $\pm 12\text{ V}$ external power supply to the power supply connector on the Probe interface. Do not switch on the power supply until the power supply connections are made using the power supply cable with or without the adapter provided.
3. When measuring currents with fast voltage variations (high dv/dt) of the primary current, connect the ground terminal on the Probe to ground.




Figure 2. Connections

exi02f.eps

Activating the Probe


There are two possibilities of supplying power to the Probe:

1. Use the recommended PSi50s Power Supply.
2. Use any suitable power supply and connect the power supply lead using the adapter provided (see Figure 2).

Note

In order for the Probe to function correctly, the characteristics of the power supply must be in accordance with the requirements in "Specifications".

Before activating the Probe, ensure that the Probe head is locked with no primary conductor (see Figure 3).



exi03f.eps

Figure 3. Locking and Unlocking the Probe

When turning on the Probe :

- All the LEDs will light up for one second.
- Demagnetization is automatically started; the DEGAUSS LED will light up for approximately six seconds.
- Auto zero is initiated to remove the residual offsets for the two ranges.

- High range (100 mV/A) is selected and the corresponding LED lights up. The Probe is now ready to measure current.

Note

Do not operate the Probe during the activation sequence.

Current Measurement

To measure current, clamp the Probe around the current carrying conductor and use the slide to ensure that the Probe head is locked (see Figure 3).

A positive output is obtained when the current flows in the direction of the arrow on the Probe head.

⚠ Caution

The performance of the Probe deteriorates if there is mechanical stress within the aperture, hindering the correct closing of the measuring head.

Note

If a 50 Ω load is used, the amplitude of the output signal is halved, and the specifications are no longer guaranteed.

Range Selection

Two ranges are available by pressing the RANGE button:

1. High range (100 mV/A): oscilloscope 1 M Ω measurement up to 30 A continuous and 50 A pk (< 10s).
2. Low range (1 V/A): oscilloscope 1 M Ω measurement up to 3 A max.

Auto Zero

An auto zero of the residual offset is initiated by pressing the AUTO ZERO button. This should only be performed when the Probe head is locked, with no primary conductor.

The auto zero can, however, be made as long as the sum of the primary current and the offset does not exceed:

- 250 mA in the low range
- 500 mA in the high range

If the above values are exceeded, all the LEDs will flash simultaneously for five seconds and the Probe will switch back to the state preceding the autozero request. The autozero function will not be performed.

Degauss

Demagnetizing of the Probe head is performed by pressing the DEGAUSS button. The Probe must remain locked without a primary conductor. During this operation, the DEGAUSS LED lights up for six seconds.

An auto zero of the residual offset is then carried out on both ranges.

Note

During this sequence, all the other controls are disabled.

Indicators

Several messages can appear on the Probe, alerting an abnormal state:

- **UNLOCKED**

When the Probe head is not locked, the UNLOCKED LED lights and flashes

- **OVERHEATING**

The OVERHEATING LED flashes when a predetermined temperature is reached; measurement is not possible while in this state. Disconnect the power supply and wait for the Probe to cool down. Check that the measured permanent current and the temperature of the primary conductor do not exceed the maximum permitted values.

- **Simultaneous flashing of all LEDs**

All the LEDs flash simultaneously for five seconds when the auto zero has not been carried out correctly. Two reasons can cause this phenomenon:

1. The Probe is strongly magnetized
2. The primary current is present during the auto zero function

The Probe reverts to the state preceding the request, i.e., an auto zero has not been performed but measurement of the current remains possible.

Power Supply Operating Instructions


⚠ Caution

To avoid damaging the Power Supply, use the following guidelines:

- **Do not disconnect the protective ground.**
- **The mains plug must be connected to a mains voltage supply with a ground terminal.**

To operate the Power Supply (see Figure 4):

1. Select the appropriate mains voltage 230 V or 115 V ac using the voltage selector switch located on the back panel.
2. Fit the rated fuse appropriate to the selected mains voltage.
3. Connect the Power Supply to the mains supply.
4. Connect the Probe(s) to the RJ45 sockets located on the front panel of the Power Supply.
5. Operate the ON/OFF switch on the back panel. The front LED will illuminate to indicate that power is being supplied to the Probe(s).



exi08f.eps

Number	Description	Number	Description
①	Probe Power Supply Connector	⑤	Power Supply Connector
②	Power Indicator	⑥	Grounding Terminal
③	Power Switch	⑦	Input Voltage Selector Switch
④	Fuse Holder		

Figure 4. PSI50s Power Supply

Fuse Rating

The Power Supply is protected by a supplied mains fuse located on the back panel. The fuse ratings depend on the applied voltage, 1 AT for 230 V and 2 AT for 115 V.

Maintenance

⚠ Caution

To prevent damage to the Probe or Power Supply:

Only trained and qualified staff should perform maintenance on the Probe.

Use only authorized repair parts and all items must be reassembled to their factory-issued configuration.

Cleaning

⚠ Caution

To prevent damage to the Probe or Power Supply when cleaning:

- **Do not use strong cleaning detergents or solvents (like trichloroethylene). Clean only using mild soap and water. After cleaning, remove all residue of soap and water.**
- **Do not allow liquid to get inside the instrument.**
- **Do not use sharp tools to clean the end faces of the Probe.**

⚠⚠ Warning

To avoid electric shock or personal injury, disconnect the power cord prior to cleaning.

If the Probe requires cleaning, wipe it with a cloth lightly dampened with a mild rinsing agent.

Power Supply Fuse Replacement

⚠ ⚠ Warning

To avoid electric shock or personal injury, ensure that the Power Supply is disconnected from the mains supply and that the Probe(s) is disconnected before changing the fuse or opening the fuse compartment.

Remove the fuse holder cover located on the rear panel and replace the fuse with an appropriately rated one, i.e., 1 AT for 230 V ac and 2 AT for 115 V ac. Re-install the fuse holder cover.

Storage

When the Probe is not going to be used, store it in the carrying case provided.

Specifications

Probe

The following lists the Probe specifications.

Electrical Specifications

Nominal current	$I_n \pm 30$ A dc or A rms
Measuring range	$I_{max} \pm 50$ A pk (duration <10 sec)
Output voltage V_o	
Low range 1 V/A	1 M Ω
High range 100 mV/A	1 M Ω
Overall accuracy (dc to 100 Hz at 25 °C)	
± 0.5 % at I_N typical	
± 1.5 % at I_N max	
Gain variation (max)	± 0.04 % of rdg/ °C
Step response	see Figure 5
Frequency response	see Figure 6
Insertion impedance Z_I	see Figure 7
< 0.1 Ω up to 10 MHz	
< 0.4 Ω 10 MHz to 50 MHz	
External magnetic field rejection rate	60 dB (ac and dc)
Rejection rate of fast dV/dt at 5 kV/ μ s	< 15 m AT (during dV/dt)
Output noise level (rms) (measured with a filter at 25 MHz)	1 m AT rms typical
Output noise level (pk to pk) (measured with a filter at 25 MHz)	9 mAT pp

Dynamic Characteristics

Bandwidth	DC to 50 MHz (-3 dB)
Frequency derating (see Figure 8)	10 A at 10 MHz
Rise time, (10 % to 90 %)	tr < 7ns
Delay time	td < 25 ns
Overshoot	< 5 % of reading

General Data

Aperture dimensions	5 x 5 mm (0.2 in x 0.2 in)
Max primary conductor temp.	60 °C (140 °F)
Dielectric withstand	1350 Vrms / 50 Hz / 1 min
Working Voltage	
CAT I	300 Vrms or dc, Pollution Degree 2
CAT II	150 Vrms or dc, Pollution Degree 2
Operating temperature	0 °C to + 40 °C (32 °F to 104 °F)
Storage temperature	-10 °C to + 60 °C (14 °F to 140 °F)
Maximum	2000 m (6600 ft)
Maximum relative humidity	80 %, 31 °C (87 °F)
Environment	indoor use only
Power supply	± 12 V, ± 0.5 V
Current consumption	
at nominal	30 A , 550 mA
during demagnetization	1.3 A (for 6 sec)
Probe dimensions	
Length	191.1 mm (7.53 in)
Width	28.9 mm (1.14 in)

Height	40.5 mm (1.59 in)
Weight	400 grams (0.88 lbs)
Output cable length	2 m (6.6 ft)

Power Supply

The following lists the specifications of the Power Supply.

Electrical

V ac Input:

Input voltage V ac	Bivoltage 115/230 V ac with manual selector On 115 V ac : 115 V ac nominal (103 V ac to 127 V ac) On 230 V ac : 230 V ac nominal (207 V ac to 253 V ac)
Frequency range of ac voltage	44 to 60 Hz
Protection fuse	1 AT / 230 V ac, 2 AT / 115 V ac, (dim: 5 x 20 mm)
Nominal rated Input current	200 mA / 230 V ac 400 mA / 115 V ac
Nominal VA rating	46 VA

V DC Outputs:

Type of adjustment	Linearly
Output voltages	± 12 V dc
Output voltage tolerances	+/- 0.5 V dc, I output 0 –1.3 A, U input: ± 10 %
Nominal output current	± 550 mA per output*
Maximum output current	± 1.3 A per output*

Protection against
short-circuits

Rectangular characteristics

* The indicated current values are valid for each output. It is possible to use the two outputs simultaneously.

Various

Operating temperature

-25, +55 °C (-13 °F, +131 °F)

Storage temperature

-40, +85 °C (-40 °F, +185 °F)

EMC

In compliance with standard EN 55022 A

Weight

2.5 kg (5.51 lb)

Dimensions

90(w) x 115(d) x 200(h)

Connectors

Via 2 RJ 45 sockets.

Safety

The Probe and Power Supply conform to the latest directives concerning safety and electromagnetic compatibility.

- European Low Voltage Directives 73/23/EEC and 93/68/EEC
- European EMC Directives 89/336/EEC and 93/68/EEC

Safety Standards

IEC61010-1:2001. General Requirements.

Safety requirements for electrical equipment for measurement, control and laboratory use.

IEC61010-2-32: 2002. Particular requirements for hand held current clamps for electrical measurement and test.

IEC61010-31: 2002. Particular requirements for hand held Probe assemblies for electrical measurement and test.

300 V rms or dc, overvoltage Cat. I, Pollution degree 1

EMC Standards

RF Susceptibility

EN 50082-1: 1992 3V/m Residential, Commercial and Light Industry

RF Emissions

EN 50081-1: 1992 Residential, Commercial and Light Industry

FCC Part 15 Class B

This product is designed to be safe under the following conditions:

- Indoor use
- Altitude up to 2000 m (6600 ft)
- Temperature 0 °C to +40 °C (32 °F to 104 °F)
- Maximum relative humidity 80 % for temperatures up to 31 °C (87 °F) decreasing linearly to 40 % relative humidity at 50 °C (122 °F)

Use of the Probe on uninsulated conductors is limited to 300 V rms or dc and frequencies below 1 kHz.




Figure 5. Step Response

exi04f.eps






Figure 6. Frequency Response

exi05f.eps



exi06f.eps

Figure 7. Insertion Impedance



exi07f.eps

Figure 8. Frequency Derating

Accessories

The following items are supplied with the Probe or the Power Supply.

- Carrying Case (Probe)
- Power Supply Cable (Probe)
- Power Supply Adapter (Probe)
- Grounding Lead (Probe)
- Users Manual (Probe)
- Calibration certificate (Probe)
- IEC Power Cord (Power Supply)
- International Adapters (Power Supply)

Service

If your Current Probe is operated and handled properly, it should not require servicing. However, if you suspect that the Transformer has failed, review this manual to ensure you are operating it correctly. If it still fails to operate properly, pack securely using the original packing material (if available) and forward, postage paid, to the nearest Fluke Service Center. Include a brief description of the problem. Fluke assumes *no* responsibility for damage in transit.

To locate an authorized service center, call Fluke using the phone numbers listed below:

USA: 1-888-99-FLUKE (1-888-993-5853)

Canada: 1-800-36-FLUKE (1-800-363-5853)

Europe: +31-402-675-200

Japan: +81-3-3434-0181

Singapore: +65-738-5655

Anywhere in the world: +1-425-446-5500

You may visit us on the World Wide Web at <http://www.fluke.com>.

To register your product, visit <http://register.fluke.com>.